

# ТАБЛИЦА ВЫБОРА ШЛЕЙФА ПИТАНИЯ

## 2-ПРОВОДНЫЕ ШЛЕЙФЫ:



|   | Артикул | Наименование       | AWG (калибр) | Сечение, мм <sup>2</sup> | Максимальный ток, А |
|---|---------|--------------------|--------------|--------------------------|---------------------|
| 1 | 033152  | ARL-16AWG-2Wire-CU | 16           | 1.31                     | 22                  |
| 2 | 026348  | ARL-18AWG-2Wire-CU | 18           | 0.82                     | 16                  |
| 3 | 026349  | ARL-20AWG-2Wire-CU | 20           | 0.52                     | 11                  |
| 4 | 031698  | ARL-22AWG-2Wire-CU | 22           | 0.33                     | 7                   |
| 5 | 033153  | ARL-24AWG-2Wire-CU | 24           | 0.21                     | 3.5                 |

## 3-ПРОВОДНЫЕ ШЛЕЙФЫ:



|   |        |                    |    |      |    |
|---|--------|--------------------|----|------|----|
| 1 | 026350 | ARL-18AWG-3Wire-CU | 18 | 0.82 | 16 |
| 2 | 026351 | ARL-20AWG-3Wire-CU | 20 | 0.52 | 11 |
| 3 | 031699 | ARL-22AWG-3Wire-CU | 22 | 0.33 | 7  |

## 4-ПРОВОДНЫЕ ШЛЕЙФЫ:



|   |        |                    |    |      |    |
|---|--------|--------------------|----|------|----|
| 1 | 033156 | ARL-16AWG-4Wire-CU | 16 | 1.31 | 22 |
| 2 | 026352 | ARL-18AWG-4Wire-CU | 18 | 0.82 | 16 |
| 3 | 026353 | ARL-20AWG-4Wire-CU | 20 | 0.52 | 11 |
| 4 | 031700 | ARL-22AWG-4Wire-CU | 22 | 0.33 | 7  |

## 5-ПРОВОДНЫЕ ШЛЕЙФЫ:



|   |        |                    |    |      |    |
|---|--------|--------------------|----|------|----|
| 1 | 033158 | ARL-16AWG-5Wire-CU | 16 | 1.31 | 22 |
| 2 | 026354 | ARL-18AWG-5Wire-CU | 18 | 0.82 | 16 |
| 3 | 026355 | ARL-20AWG-5Wire-CU | 20 | 0.52 | 11 |
| 4 | 031701 | ARL-22AWG-5Wire-CU | 22 | 0.33 | 7  |

## 6-ПРОВОДНОЙ ШЛЕЙФ:



|   |        |                    |    |      |    |
|---|--------|--------------------|----|------|----|
| 1 | 031703 | ARL-18AWG-6Wire-CU | 18 | 0.82 | 16 |
|---|--------|--------------------|----|------|----|

